

LITTLE BUDDY

ATTACHMENT



Best of both worlds!



Want the ability to drive big posts and T-posts at any given time?

We have the solution! Our T-Rex 350E mounts onto the side of the 750R, 1000E and 1500E, giving you the option of conveniently driving big posts and T-posts without switching attachments.

The Little Buddy can easily be added onto your Montana Post Driver with very little time and hassle.

The check valves included in the Little Buddy kit in the hydraulic lines, allow your post driver to operate by running your hydraulic switch in one direction and the T-Rex to operate by running your hydraulic switch in the opposite direction.

T-REX 350E Little Buddy

A	B	E	F	G	H	I	J	K	L	M	N
Domed Tool	Flat Tool	Chain	Nitrogen Bottle	Nitrogen Charge Kit	Hydraulic Hoses	Price	Shipping WxLxH	Oil Flow	Min PSI	Blow Rate	Standard Tool ID
✓		✓		✓	✓	\$3,400	18x30x24	5-20	1300	700-1200	4 3/8"
Little Buddy Kit (everything except the 350E Driver)						\$350					

LITTLE BUDDY

Mounting Instructions



Supplied Parts

- (1) T-REX 350E (Little Buddy)
- (1) Little Buddy Mounting Plate
- (2) $\frac{3}{8}$ " Hoses
- (3) $\frac{3}{4} \times 4$ " Bolts with nuts and washers
- (3) $\frac{5}{8} \times 2$ " Bolts with nuts and washers
- (2) Check Valves
- (2) Tees

- 1 Remove bottom 3 mounting bolts from side of post driver opposite the hoses, and bolt Little Buddy mounting plate to driver with 3- $\frac{3}{4} \times 4$ " bolts.
- 2 Remove both hoses/elbows from driver.
- 3 Remove hydraulic fitting from out port of driver and replace with check valve.
- 4 Add 2 hydraulic tee fittings.
- 5 Install Little Buddy $\frac{3}{8}$ " hoses. Hose coming from in port on T-Rex goes to out port on driver. Hose coming from out port on T-Rex goes to in port on driver.
- 6 Attach hoses/elbows to the tee. Hose with female quick coupler attaches to tee on out port. Hose with male quick coupler attaches to tee on in port.

